



E100 Quick Start User Guide

Basic functions



- Switch on
- Switch off
- Volume control
- Confirm selection
- Navigate menu


The first time the unit is activated it will perform a DAB scan. Make sure that a suitable DAB aerial is connected to the unit and wait for the DAB scan to complete. Once the scan is complete the unit will immediately start to play the first station on the list.

DAB Radio




- Select DAB source
- Scroll lower frequency
- Scroll higher frequency
- Select station
- Press and hold to store selected station
- Press once to switch to a stored station

FM Radio



- Select FM source
- Scan to next available station
- Scan lower frequency
- Scan higher frequency
- Press and hold to store selected station
- Press once to switch to a stored station

Bluetooth



- Select Bluetooth source
E100 appears as **Systemline-00** as default on your mobile device Bluetooth listing
- Press to select Yes
- Once pairing is available, press Enter

Changing source will automatically pause mobile device. Bluetooth connection is dropped when E100 is in standby. To reconnect, select Bluetooth as source and wait for 'Bluetooth connected' to be displayed.

Aux in



- Select Aux in source
Auxilliary input will become active on selection

 **E100 System Schematic**

